1870022 K-Blue Locker Nightstand
1870035 K-Red Locker Nightstand

Parts List

A.	Top Assembly	1 pc
B.	Adjustable Shelf	1 pc
C.	Casters	4 pcs

* Please make sure that you have all the parts indicated above before you begin assembly of this item.
* This item is to be assembled by an adult and is not intended to be taken apart by a child.

Assembly Instruction

1. **Attach Casters (C)** Put the Top Assembly (A) upside down on a soft surface. Align the exposed threads of the Casters (C) with the pre-threaded holes in the bottom of Top Assembly (A). Tighten by turning in a clockwise direction. See Illustration #1.
2. **Attach Adjustable Shelf (B)** Put the Adjustable Shelf (B) on shelf pins. **Note: Tube frame on Adjustable Shelf (B) should face down. You can adjust the shelf pins by turning in a counter clockwise direction and replacing them at the desired height.**





R2-6-21-04